

## Using the Corvette navigation system - Index and Quick reference.

<u>Section</u>	<u>Document</u>	<u>Page</u>
<b>Section 1. Setting up the navigation system. –</b> Setting the correct region User settings Quick points of interest	<b>Part 1</b>	<b>page 5.</b> page 6. page 7. page 8.
<b>Section 2 Entering a destination</b> Menu selections Entering an address Route options - route info Route options – cancel guidance Display route Turn list	<b>Part 1,</b>	<b>page 9.</b> page 9 page 10. page 12. page 14 page 15 page 15
<b>Section 3 Other means of destination entry</b> Select from map Phone number	<b>Part 2</b>	<b>page 17.</b> page 18. page 19.
<b>Section 4. Points of Interest</b> POI by city or name POI by Quick POI or map POI Info POI voice recognition commands	<b>Part 2.</b>	<b>page 21.</b> page 22. page 25. page 26. page 27.
<b>Section 5. Waypoints</b> Storing waypoints via the Enter Destination menu Storing waypoints via the Destination and Waypoint menu	<b>Part 3</b>	<b>page 28.</b> page 29. page 31.
<b>Section 6. Storing a memory point</b> Storing a memory point from the map screen Adding or editing a memory point name Adding or editing a memory point phone number Deleting one or all memory points	<b>Part 3</b>	<b>page 32.</b> page 34. page 36. page 36. page 38.
<b>Section 7. Previous destinations</b> Using a previous start point Using a previous destination from the list	<b>Part 4</b>	<b>page 39</b> page 40. page 41.
<b>Section 8. Preset destinations</b> Entering a Preset destination Editing a Preset destination Using a preset destination.	<b>Part 4</b>	<b>page 42.</b> page 42. page 43. page 44.
<b>Section 9. Map modes</b> Single map mode Dual map mode Turn list map mode Next turn map mode Highway guidance map mode	<b>Part 5</b>	<b>page 46.</b> page 47. page 48. page 48. page 49. page 49.
<b>Section 10. Functions available while driving.</b>	<b>Part 6</b>	<b>page 51.</b>